

3 YEAR
PRODUCT
WARRANTY



UNIMIG® RAZOR CUT 120

U14002K | Operating Manual





CONTENTS

SAFETY.....	4
TECHNICAL DATA.....	7
MACHINE LAYOUT.....	8
WHAT'S IN THE BOX.....	10
GENERAL OPERATING TIPS.....	11
DIGITAL SCREEN OPERATION.....	12
CNC SETUP.....	15
SETUP FOR INTERNAL AIR PLASMA CUTTING.....	16
PLASMA CUTTING TECHNOLOGY.....	19
PLASMA CUTTING TIPS & TECHNIQUES.....	20
TORCH BREAKDOWN & SPARES.....	22
MACHINE PARTS BREAKDOWN.....	23
FAQ & TROUBLESHOOTING.....	24

Welding and cutting equipment can be dangerous to both the operator and people in or near the surrounding working area if the equipment is not correctly operated. Equipment must only be used under the strict and comprehensive observance of all relevant safety regulations.

Read and understand this instruction manual carefully before the installation and operation of this equipment.

WARNING: USE COMPRESSED AIR ONLY WITH THIS MACHINE

Machine Operating Safety

- Do not switch the function modes while the machine is operating. Switching of the function modes during welding can damage the machine. Damage caused in this manner will not be covered under warranty.
- Disconnect the electrode-holder cable from the machine before switching on the machine, to avoid arcing should the electrode be in contact with the workpiece.
- Operators should be trained and or qualified.



Electric shock: It can kill. Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and internal machine circuits are also live when power is on. In MIG/MAG welding, the wire, drive rollers, wire feed housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is dangerous.

- Connect the primary input cable, according to Australian and New Zealand standards and regulations.
- Avoid all contact with live electrical parts of the welding/cutting circuit, electrodes and wires with bare hands.
- The operator must wear dry welding gloves while he/she performs the welding/cutting task.
- The operator should keep the workpiece insulated from himself/herself.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cable for wear and tear, replace the cable immediately if damaged, bare wiring is dangerous and can kill.
- Do not weld or plasma cut in the rain.
- Do not use damaged, undersized, or badly joined cables.
- Do not drape cables over your body.
- We recommend (RCD) safety switch is used with this equipment to detect any leakage of current to earth.



Fumes and gases are dangerous. Smoke and gas generated while welding or cutting can be harmful to people's health. Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Do not breathe the smoke and gas generated while welding or cutting, keep your head out of the fumes.
- Keep the working area well ventilated, use fume extraction or ventilation to remove welding/cutting fumes and gases.
- In confined or heavy fume environments always wear an approved air-supplied respirator.
- Welding/cutting fumes and gases can displace air and lower the oxygen level, causing injury or death. Be sure the breathing air is safe.
- Do not weld/cut in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapours to form highly toxic and irritating gases.
- Materials such as galvanised, lead, or cadmium plated steel, containing elements that can give off toxic fumes when welded/cut. Do not weld/cut these materials unless the area is very well ventilated, and or wearing an air-supplied respirator.



Arc rays: harmful to people's eyes and skin. Arc rays from the welding/cutting process produce intense visible and invisible ultraviolet and infrared rays that can burn eyes and skin.

- Always wear a welding helmet with the correct shade of filter lens and suitable protective clothing, including welding gloves while the welding/cutting operation is performed.
- Measures should be taken to protect people in or near the surrounding working area. Use protective screens or barriers to protect others from flash, glare and sparks; warn others not to watch the arc.



Fire hazard. Welding/cutting on closed containers, such as tanks, drums, or pipes, can cause them to explode. Flying sparks from the welding/cutting arc, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of the electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding/cutting.

- The welding/cutting sparks & spatter may cause fire, therefore remove any flammable materials well away from the working area. Cover flammable materials and containers with approved covers if unable to be moved from the welding/cutting area.
- Do not weld/cut on closed containers such as tanks, drums, or pipes, unless they are correctly prepared according to the required Safety Standards to ensure that flammable or toxic vapours and substances are totally removed, these can cause an explosion even though the vessel has been “cleaned”. Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Do not weld/cut where the atmosphere may contain flammable dust, gas, or liquid vapours (such as petrol)
- Have a fire extinguisher nearby and know how to use it. Be alert that welding/cutting sparks and hot materials from welding/cutting can easily go through small cracks and openings to adjacent areas. Be aware that welding/cutting on a ceiling, floor, bulkhead, or partition can cause a fire on the hidden side.



Gas Cylinders. Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Because gas cylinders usually are part of the welding/cutting process, be sure to treat them carefully. CYLINDERS can explode if damaged.

- Protect gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Ensure cylinders are held secure and upright to prevent tipping or falling over.
- Never allow the welding/cutting electrode or earth clamp to touch the gas cylinder, do not drape welding cables over the cylinder.
- Never weld/cut on a pressurised gas cylinder, it will explode and kill you.
- Open the cylinder valve slowly and turn your face away from the cylinder outlet valve and gas regulator.



Gas build-up. The build-up of gas can cause a toxic environment, deplete the oxygen content in the air resulting in death or injury. Many gases use in welding/cutting are invisible and odourless.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



Electronic magnetic fields. MAGNETIC FIELDS can affect Implanted Medical Devices.

- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near any electric welding, cutting or heating operation.



Noise can damage hearing. Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



Hot parts. Items being welded/cut generate and hold high heat and can cause severe burns.

- Do not touch hot parts with bare hands. Allow a cooling period before working on the welding/cutting gun. Use insulated welding gloves and clothing to handle hot parts and prevent burns.

CAUTION

1. Working Environment.

- i. The environment in which this welding/cutting equipment is installed must be free of grinding dust, corrosive chemicals, flammable gas or materials etc., and at no more than a maximum of 80% humidity.
- ii. When using the machine outdoors, protect the machine from direct sunlight, rainwater and snow, etc.; the temperature of the working environment should be maintained within -10°C to +40°C.
- iii. Keep this equipment 30cm distant from the wall.
- iv. Ensure the working environment is well ventilated.

2. Safety Tips.

- i. **Ventilation:** This equipment is small-sized, compact in structure, and of excellent performance in amperage output. The fan is used to dissipate heat generated by this equipment during the welding/cutting operation. Important: Maintain good ventilation of the louvres of this equipment. The minimum distance between this equipment and any other objects in or near the working area should be 30 cm. Good ventilation is of critical importance for the normal performance and service life of this equipment.
- ii. **Thermal Overload Protection:** Should the machine be used to an excessive level, or in a high-temperature environment, poorly ventilated area or if the fan malfunctions the Thermal Overload Switch will be activated, and the machine will cease to operate. Under this circumstance, leave the machine switched on to keep the built-in fan working to bring down the temperature inside the equipment. The machine will be ready for use again when the internal temperature reaches a safe level.
- iii. **Over-Voltage Supply:** Regarding the power supply voltage range of the machine, please refer to the “Main parameter” table. This equipment is of automatic voltage compensation, which enables the maintaining of the voltage range within the given range. In case that the voltage of input power supply amperage exceeds the stipulated value, it is possible to cause damage to the components of this equipment. Please ensure your primary power supply is correct.
- iv. Do not come into contact with the output terminals while the machine is in operation. An electric shock may occur.

MAINTENANCE

Exposure to extremely dusty, damp, or corrosive air is damaging to the welding/cutting machine. To prevent any possible failure or fault of this welding/cutting equipment, clean the dust at regular intervals with clean and dry compressed air of required pressure.

Please note that: lack of maintenance can result in the cancellation of the guarantee; the guarantee of this welding/cutting equipment will be void if the machine has been modified, attempt to take apart the machine or open the factory-made sealing of the machine without the consent of an authorized representative of the manufacturer.

TROUBLESHOOTING

Caution: Only qualified technicians are authorized to undertake the repair of this welding/cutting equipment. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed in this manual.

RAZOR™ CUT 120 Plasma Cutter

Key Features:

- CNC Connection
- Pilot Arc Start
- Digital Screen
- 45mm Clean Cut
- 60mm Severance
- 2T/4T Torch Controls
- Air Test

3 YEAR
PRODUCT
WARRANTY



TECHNICAL DATA	
SKU	U14002K
PRIMARY INPUT VOLTAGE	415V Three Phase
SUPPLY PLUG	No plug supplied (32 AMP Recommended)
RATED INPUT CURRENT (A)	26
NO LOAD VOLTAGE (V)	420
I _{eff} (A)	26
AIR FLOW DRAW OFF (L/min)	189
AIR FLOW PRESSURE (Bar)	5.17 (75 psi)
PROTECTION CLASS	IP21
INSULATION CLASS	H
DINSE CONNECTOR	10/25
STANDARD	AS/NZ60974-1
WARRANTY (Years)	3

PLASMA CUT SPECIFICATIONS	
PLASMA CUT CURRENT RANGE	20-120A
PLASMA CUT DUTY CYCLE @ 40°C	60% @ 120A 100% @ 100A
MILD STEEL CUT THICKNESS	45mm
MILD STEEL SEVERANCE THICKNESS	60mm
ALUMINIUM CUT THICKNESS	36mm
STAINLESS STEEL CUT THICKNESS	45mm

SIZE & WEIGHT	
DIMENSIONS (mm)	
WEIGHT (kg)	24kg

MACHINE FEATURES	
PLASMA ARC START	Pilot Arc
CNC CONNECTION	Yes
THERMAL OVERLOAD PROTECTION	Over Temperature Warning

Recommended Accessories



Plasma Cutter Air Filter


50500

See page 21




SCM80R Plasma Torch

SCM80R




Front Panel Layout

1. Selector Knob
2. Selector Button / Air Test Button
3. Digital Screen
4. Plasma Torch Connection
5. Earth Clamp Connection (10/25 Dinse)
6. CNC Connection



Rear Panel Layout


7. Air Pressure Regulator Knob
8. Air Pressure Regulator Outlet Pressure Gauge
9. Compressed Air Inlet / Gas Inlet Connector
10. Air Condensate Filter / Trap
11. On/off switch




Digital Screen Layout

- 12.** Normal Cutting Mode
- 13.** Current Display
- 14.** Perforated Cutting Mode
- 15.** Post-flow Display
- 16.** Current Adjustment Selector
- 17.** Post-flow Adjustment Selector
- 18.** Bar Display

WHAT'S IN THE BOX




RAZOR CUT 120 Plasma Cutter




Includes:

- 1 x Cooling Tube
- 1 x Electrode
- 1 x O ring
- 1 x Cutting Tip
- 1 x Retaining Cap
- 1 x Stand Off Guide

6m SC120 Plasma Torch



4m 300 AMP Earth Clamp



Air Regulator



Operating Manual

Additional Machine Control Information

Compressed Air Requirements

A reliable and consistent supply of clean, dry compressed air is essential for proper operation. Although the machine contains its own internal air supply filtration system it is recommended the compressed air supply should have external filtration in the line feeding the machine, both a standard water trap (sintered bronze filter) and also a coalescing filter (for oil in the air). The air requirement is a minimum of 120 L/min (4.5cfm) Free Air Delivery (FAD) at 75psi pressure. This usually means the compressor must be a belt-drive model or if a direct drive, it must have a motor power of 2.5HP or higher.

The air must be dry and free of oil and moisture (usually a symptom of older, worn-out compressors). The air hose must also be of sufficient size (3/8"/10mm minimum) to supply the machine.

Operation environment

- Height above sea level ≤ 1000 M
- Operation temperature range -10 to +40°C
- Air relative humidity is below 90 % (20°C)
- Preferably sit the machine above the floor level, and the maximum angle does not exceed 15°.
- Protect the machine against heavy rain AND against direct sunshine.
- The content of dust, acid, corrosive gas in the surrounding air or substance cannot exceed the normal standard.
- Take care that there is sufficient ventilation during plasma cutting. There must be at least 30cm free distance between the machine and wall.

Operation Notices


- Read this manual carefully before starting to use this equipment.
- Connect the ground wire with the machine directly.
- Ensure that the input is three-phase: 50/60Hz, 415V $\pm 10\%$.
- Before operation, clear all unnecessary personal from the work area.
- Do not watch the arc in unprotected eyes.
- Ensure proper ventilation of the machine to improve the Duty Cycle.
- Turn off the machine when the operation finished for energy consumption efficiency.
- When the power switch shuts off protectively because of failure, don't restart it until the problem is resolved. Otherwise, the range of the problem will be extended.
- In case of problems, contact your local dealer if no authorized maintenance staff is available



Compressed Air Testing/Setting

Hold the "Air Test" button for 2 seconds to enter the Air Test option, and the screen will display the above interface.

As you continue to hold the "Air Test" button down, the air test will run. To end the air test, release the "Air Test" button.



Error Display

1. AIR Error Display

The above interface is displayed when the machine has no gas input, or the air pressure is low.

Correct air pressure is critical for plasma cutting. Incorrect air pressure will cause poor cut quality, a lack of cutting power, damage to the plasma torch and consumables and potentially damage to the power source. Optimum air pressure is between 0.45 and 0.5MPa (65-75psi). The air pressure should be set with the air flowing through the torch, as the pressure with the air flowing will normally be less than static pressure due to flow losses through the torch system. To unlock the pressure regulator knob in order to adjust it, pull the knob upwards. The regulator knob can be found on the back of the machine. Once the pressure is set correctly, push the knob down again to lock it into place.

2. Torch Error Display

This error will light up when an issue with the torch system or the air supply is detected, and the output is disabled as a result. A flashing light means that the torch's shield cap is not installed. A continuous light means that the torch consumables could be damaged or missing, or there is insufficient air pressure supply to the torch.

3. Over Temp Error Display

This error will light up when the machine is over voltage, over current or overheating (due to exceeding the duty cycle), and protection is activated. When protection is activated, the cutting output will be disabled until the safety system senses the overload has reduced sufficiently and the indicator lamp goes out. This error may also trigger if the machine experiences an internal power circuit failure.

4. Phase Loss Error Display


This error will display when there is a loss of power. Check the power supply to ensure power is still active and being delivered.

System Setup Interface

Hold the Selector Knob for 3 seconds to enter the settings interface. Press the Selector Button / Air Test Button to switch between the options (below) in the settings interface and set/adjust the parameters using the Selector Knob. To exit the system menu, hold the Selector Knob for 3 seconds.



1. Language Selector



2. Brightness Adjustment



3. Current Software



4. Factory Reset

CNC Socket

The RAZOR CUT 120 is equipped with an optional, factory-installed, four-position voltage divider that is designed to be safely connected without tools. The built-in voltage divider provides a scaled-down arc voltage of 20:1, 30:1, 40:1, and 50:1 (maximum output of 18V). An optional receptacle on the rear of the power supply provides access to the scaled-down arc voltage and signals for arc transfer and plasma start.

Note: The factory presets the voltage divider to 20:1. To change the voltage divider to a different setting, refer to the section on the next page.



The factory-installed internal voltage divider provides a maximum of 18V under open-circuit conditions. This is an impedance-protected functional extra-low voltage (ELV) output to prevent shock, energy, and fire under normal conditions at the machine interface receptacle and under single fault conditions with the machine interface wiring. The voltage divider is not fault-tolerant, and ELV outputs do not comply with safety extra-low voltage (SELV) requirements for direct connection to computer products.

The cover on the machine interface receptacle prevents dust and moisture from damaging the receptacle when not in use. This cover should be replaced if damaged or lost.

Installation of the machine interface cable must be performed by a qualified service technician. To install a machine interface cable:

1. Turn OFF the power and disconnect the power cord.
2. Remove the machine interface receptacle's cover from the rear of the power supply.
3. Connect the machine interface cable to the power supply.

Refer to the following table when connecting the CUT system to a torch height controller or CNC controller with a machine interface cable.

SIGNAL	TYPE	INSTRUCTION	SOCKET	CABLE ENDS
Start (start plasma)	Input	<ul style="list-style-type: none"> • Normally open. • 18 VDC open circuit voltage at START terminals. • Requires dry contact closure to activate. 	3, 4	3 (Yellow), 4 (Green)
Transfer (start machine motion)	Output	<ul style="list-style-type: none"> • Normally open. Dry contact closure when the arc transfers. • 120 VAC/1 A maximum at the machine interface relay switching device (supplied by the customer). 	12, 14	12 (Blue), 14 (White)
Ground	Ground		13	
Voltage divider	Output	<ul style="list-style-type: none"> • CUT: Divided arc signal of 20:1, 30:1, 40:1, 50:1 (Provides a maximum of 18V). 	5, 6	5 (Black), 6 (Red)

Five Position Voltage Divider


The factory presets the voltage divider to 20:1. To change the voltage divider to a different setting:

1. Turn OFF the power supply and disconnect the power cord.
2. Remove the power supply cover.
3. Locate the voltage divider DIP switches on the left side of the power supply.


	SCALE	20:1	30:1	40:1	50:1
POSITION	1	ON	1	1	1
	2	2	ON	2	2
	3	3	3	ON	3
	4	4	4	4	ON

SETUP FOR INTERNAL AIR PLASMA CUTTING


- 1 Connect the plasma torch to the plasma torch connection. Tighten the nut once connected to ensure a secure connection.




- 2 Connect the earth clamp to the **positive (+)** dinse connection, twist to lock in place



- 3 Connect the plug into power, then switch the machine ON.




- 4 Perform an **Air Test** by holding down the Air Test Button for 2s, to check that air is feeding correctly.




SETUP FOR INTERNAL AIR PLASMA CUTTING


- 5 Connect the earth clamp to the work piece.




- 6 Select cutting mode by pressing the **Selector Button** until the desired cutting mode is highlighted.



- 7 Set the current to turning the **Selector Knob**.




- 8 Set the Post Flow (5-120s) by pushing the **Selector Knob** to cycle between Current and Post-Flow. Once Post-Flow is highlighted, turn the **Selector Knob** to set the desired Post-Flow.




SETUP FOR INTERNAL AIR PLASMA CUTTING


- 9** Place and hold the torch vertical at the edge of the plate.



- 10** Pull the trigger to energise the arc. When the cutting arc has cut through the edge of the plate start moving evenly in the direction you wish to cut.



- 11** To finish the cutting release the torch switch. The air flow will continue according to the set Post-Flow to cool the torch head. Do not disconnect air until this cooling period has been completed. Failure to do this will result in torch head damage.



PLASMA CUTTING TECHNOLOGY


Plasma cutters work by passing an electric arc through a gas that is passing through a constricted opening. The electric arc elevates the temperature of the gas to the point that it enters a 4th state of matter. We all are familiar with the first three: i.e., Solid, liquid, and gas. Scientists call this additional state plasma. As the metal being cut is part of the circuit, the electrical conductivity of the plasma causes the arc to transfer to the work. The restricted opening (Tip) the gas passes through causes it to squeeze by at high speed, like air passing through a venturi in a carburettor. This high-speed gas cuts through the molten metal. Plasma cutting was invented as a result of trying to develop a better welding process. Many improvements then led to making this technology what it is today. Plasma cutters provide the best combination of accuracy, speed, and affordability for producing a variety of flat metal shapes. They can cut much finer and faster than oxy-acetylene torches.

How a plasma cutter works:

Basic plasma cutters use electricity to superheat air into plasma (the 4th state of matter), which is then blown through the metal to be cut. Plasma cutters require a compressed air supply and AC power to operate.

Operation:

1. When the trigger is squeezed, DC current flows through the torch lead into the tip.
2. Next, compressed air flows through the torch head, through the air diffuser that spirals the airflow around the electrode and through the hole of the cutting tip.
3. A fixed gap is established between the electrode and the tip. (The power supply increases voltage in order to maintain a constant current through the joint.) Electrons arc across the gap, ionizing and superheating the air creating a plasma stream.
4. Finally, the regulated DC current is switched so that it no longer flows to the tip but instead flows from the electrode to the workpiece. Current and airflow continue until cutting is stopped.



The nozzle and electrode require periodic replacement. The electrode has an insert of a tough high conductive material such as hafnium and cerium. This insert erodes with use; also, the tip orifice will erode with use. Quality of the air used is paramount to longer life of electrodes and tips, in short, clean dry air gives more extended parts life, the cleaner and dryer the better. We recommend the use of a Plasma Air Filter.

What kinds of materials can the plasma cut?

Virtually any metal can be plasma cut including steel, stainless steel, aluminium, brass, copper, etc. Any thickness from 30 gauge through 30mm can be cut, depending on the power of the plasma cutter used.

How Does Plasma Cutting Compare to Oxy-fuel (gas) cutting?

Plasma cutting can be performed on any conductive metal - mild steel, aluminium and stainless are some examples. With mild steel, operators will experience faster, thicker cuts than with alloys.

Oxy-fuel cuts by burning, or oxidizing the metal it is severanceing. It is therefore limited to steel and other ferrous metals which support the oxidizing process. Metals like aluminium and stainless steel form an oxide that inhibits further oxidization, making conventional oxy-fuel cutting impossible. Plasma cutting, however, does not rely on oxidation to work and thus it can cut aluminium, stainless and any other conductive material. While different gasses can be used for plasma cutting, most people today use compressed air for the plasma gas. In most shops, compressed air is readily available, and thus plasma does not require fuel gas and compressed oxygen for operation.

Plasma cutting is typically more accessible for the novice to master, and on thinner materials, plasma cutting is much faster than oxy-fuel cutting. However, for heavy sections of steel (25mm and greater), oxy-fuel is still preferred since oxy-fuel is typically faster and, for heavier plate applications, high powered plasma machines are required for plasma cutting applications.

What are the limitations to Plasma Cutting? Where is Oxy-fuel preferred?

The plasma cutting machines are typically more expensive than oxy/acetylene. Also, oxy/acetylene does not require access to electrical power or compressed air which may make it a more convenient method for some users. Oxy-fuel can generally cut thicker sections (>25mm) of steel more quickly than plasma.

PLASMA CUTTING TIPS & TECHNIQUES

Amperage

The standard rule of thumb is the thicker the material, the more amperage required. On thick material, set the machine to full output and vary your travel speed. On thinner material, you need to turn down the amperage and change to a lower-amperage tip to maintain a narrow kerf. The kerf is the width of the cut material that is removed during cutting.

Speed


Amperage and speed are critical to producing a good quality cut. The faster you move (especially on aluminium), the cleaner your cut will be. To determine if you're going too fast or too slow, visually follow the arc that is coming from the bottom of the cut. The arc should exit the material at a slight angle away from the direction of travel. If it's going straight down, that means you're going too slow, and you'll have an unnecessary build-up of dross or slag. If you go too fast, it will start spraying back onto the surface of the material without cutting all the way through. Because the arc trails at an angle, at the end of a cut, slow your cutting speed and angle the torch in to cut through the last bit of metal.

Direction


It is easier to pull the torch towards you than push it. The plasma stream swirls as it exits the tip, biting one side and finishing off on the other, leaving a bevelled edge and a straight edge. The bevel cut effect is more noticeable on thicker material and needs to be taken into consideration before starting your cut as you want the straight side of the cut to be on the finished piece you keep.

Torch tip height & position


The distance and position of the plasma torch cutting tip affect the quality of the cut and the extent of the bevel of the cut. The easiest way to reduce bevel is by cutting at the proper speed and height for the material and amperage that is being cut.




Correct torch height and square to the material.
Minimum bevel & equal bevel
Longest consumable life.




Torch angled to the material.
Unequal bevel, one side may be excessively bevelled.



Torch height too high.
Excessive bevel, plasma stream may not cut all the way through the material.



Torch height too low. Reverse bevel. The tip may contact the work and short out or damage the tip.



If sparks are spraying up from the work piece, you are moving the torch too fast, or you don't have enough amps set.

Tip size and condition

The tip orifices focus the plasma stream to the workpiece. It is essential to use the correct size tip for the amperage being used, for example, a tip with a 1.0mm orifice is suitable for 0-40 amps whereas a 1.3mm orifice is better for 40-80 amps. The low-amp tip has a smaller orifice which maintains a narrow plasma stream at lower settings for use on thin-gauge material. Using a 25 amp tip at a 60 amp setting will blow out and distort the tip orifice and require replacement. Conversely, using an 80-amp tip on the lower settings will not allow you to focus the plasma stream as well and creates a wide kerf. The condition of the tip orifice is critical to the quality of the cut result, a worn or damaged tip orifice will produce a distorted plasma stream resulting in poor cut quality.

Electrode condition

A fixed gap is established between the electrode and the inside of the cutting tip — electrons arc across the gap, ionizing and superheating the air creating the plasma stream. The electrode contains an insert at the end made of a highly conductive material called hafnium. This insert erodes with use and develops a pit at the end of the electrode when the pit becomes too much poor-quality cuts will result and necessitate replacement of the electrode.

Air pressure and volume

Air pressure, flow rate and air quality are critical to quality plasma cutting and consumable life span. The required air pressure and volume can vary from model to model, and the manufacturer will provide the specs.

The RAZOR CUT 120 air pressure must be adjusted and set to 0.5MPA (75psi) and requires a flow rate of 120 L/min. The volume capacity of your compressor is important. If you have a small compressor with precisely the same L/min rating as the plasma, then the compressor will run continuously when you are plasma cutting. A compressor with a L/min rating slightly higher than the plasma would be more than adequate.

If you are doing a lot of cutting, cutting thick plate (same air consumption but slower cut speeds = longer cut time), then choose a compressor at 1.5 to 2 times the plasma system requirement.

Air quality

Good, dry air is essential to quality plasma cutting and consumable life span.

Compressors take in air at atmospheric pressure and increase the pressure and store it in a tank. Humidity in the air is condensed in the tank and the airlines producing water, more so in humid environments. Moisture that forms in airlines tends to condense into larger drops when the air pressure decreases as it is entering the plasma torch. When these droplets enter into the high temperatures (as much as 11,000°C) in the plenum of the torch, they immediately break down into oxygen and hydrogen, which alters the regular chemical content of the air in the torch. These elements will then dramatically change the plasma arc which causes the torch consumable parts to wear very quickly, alters the shape of the nozzle orifice, dramatically affecting cut quality in terms of edge squareness, dross formation, and edge smoothness.

Minimising the moisture in the air supply is absolutely critical to quality plasma cuts and longevity of consumable parts. As a minimum be sure to drain the receiver (tank) on the air compressor at least daily.

Most air plasma systems from reputable manufacturers have an onboard particulate filter and or a coalescing filter with an auto drain that will remove some moisture from the air supply. For home workshop and light industrial users, the onboard air filter is adequate. Most situations, however, will require additional filtration to prevent moisture from affecting the quality of the plasma cutter and in most cases, it is recommended to install a submicronic particulate filter that is designed to trap water through absorption. This style of filter has a replaceable filter cartridge that absorbs water and must be changed after it is near saturation; it should be installed close as possible to the air intake of the plasma cutter.

General Tips

- It is easier to pull the torch through the cut than to push it.
- To cut thin material, reduce the amperage until you get the best quality cut.
- Use the correct size tip orifice for the amperage being used.
- For straight cuts use a straight edge or cutting buggy as a guide. For circles, use a template or circle cutting attachment.
- Check that the front end consumable parts of the plasma cutting torch are in good condition.




Plasma Cutter Air Filter

SKU: 50500

Most situations, however, will require additional filtration to prevent moisture from affecting the quality of the plasma cutter and in most cases, it is recommended to install a submicronic particulate filter that is designed to trap water through absorption.

TORCH BREAKDOWN & SPARES

SC120 Plasma Torch




Length	6m
SKU	WG-SC120-60-CC1

TORCH SPARES		
1	SC1201	SC120 Torch Head Kit
2	SC8014	Plasma Handle Kit
3	SCSP1	Screw Pack
4	SC2516	Plasma Safety Trigger
5	SC8015	Location Block
6	SC8019-60-CF4	Cable Assembly Complete X 6mt
7	SC1250	Circle Cutting Attachment Kit
8	SC1202	Cooling Tube
9	PSC1204	Electrode
10	SC1207	Swirl Ring
11	SC1206	Swirl Ring - Heavy Duty
12	PSC1220-10	Cutting Tip 1.0mm 40-50A
	PSC1220-11	Cutting Tip 1.1mm 50-60A
	PSC1220-12	Cutting Tip 1.2mm 60-70A
	PSC1221-14	Cutting Tip 1.4mm 80-90A
	PSC1221-15	Cutting Tip 1.5mm 100-110A
	PSC1221-16	Cutting Tip 1.6mm 110-120A
13	PSC1226-10	Contact Cutting Tip 1.0mm 40-50A
	PSC1226-11	Contact Cutting Tip 1.1mm 50-60A
	PSC1226-12	Contact Cutting Tip 1.2mm 60-70A
	PSC1227-14	Contact Cutting Tip 1.4mm 80-90A
	PSC1227-15	Contact Cutting Tip 1.5mm 100-110A
	PSC1227-16	Contact Cutting Tip 1.6mm 110-120A
	PSC8026-13	Cutting Tip Contact 1.3mm
14	SC1228-22	Gouging Tip 2.2mm
15	SC1230	Retaining Cap 30-70A
	SC1231	Retaining Cap 80-120A

TORCH SPARES		
16	SC1232	Shield Cap Body
17	SC1251	Cutting Buggy
18	SC1240	Stand-off Guide
19	SC8041	Shield Cap
20	SC1241	Shield Cap
21	SC8043	Shield Cap Gouging
22	SC1208	O Ring

TECHNICAL DATA	
COOLING METHOD	Air Cooled
DUTY CYCLE	60% @ 120A
CUTTING THICKNESS	20-25mm
GAS	Air/N2
GAS PRESSURE	4.5-5.0 Bar / 65-75 psi
GAS FLOW	110L/min
IGNITION	Pilot Arc
POST FLOW	90s
LENGTHS (m)	6
STANDARD	EN60974-7

MACHINE PARTS BREAKDOWN



MACHINE SPARES

1	7.0510.0790	Right panel
2	7.3010.0790	Machine cover
3	7.2530.004	Handle
4	7.0500.0790	Left panel
5	7.1230.043	Gas valve assembly sheet
6	6.6240.103	T shape three way joint
7	6.6240.003	plastic two way joint
8	3.0628.7009	capacitance panel
9	3.0628.5001	3 phase drive panel
10	7.0620.0790	fixing plate for PCB
11	7.1230.042	plastic holder
12	7.1230.041	wind guide cover
13	6.7200.002	fan
14	7.1220.0790	Fan mounting sheet
15	7.0680.0790	Rear panel
16	6.2530.201	Oil-water separator
17	6.2320.303	rotary switch
18	6.1550.003	fixing clamp for power cable
19	7.7130.019	insulation part
20	7.1230.039	Insulation panel(1)
21	6.4630.001	Sensorless thin film capacitance
22	6.4250.101	IGBT module
23	6.2310.001	Thermistor
24	7.5110.012	Connector
25	7.15110.013	Connector
26	6.4110.201	3 phase rectifier bridge
27	7.5110.014	connector
28	7.4220.053	heat sink
29	7.1230.040	Insulation panel(2)
30	7.0460.004	holder
31	7.0550.0790	Bottom panel

MACHINE SPARES

32	3.0628.7006	Three-phase high frequency board
33	7.1230.038	cement resistor assembly sheet
34	6.4450.001	cement resistor
35	5.1850.0790	main transformer
36	5.2710.0790	inductance
37	5.2710.9009	High Frequency inductance
38	7.1230.061-A	Central socket fixing plate
39	7.0690.929	Front panel
40	6.1320.114-A	14 pin socket
41	6.6670.002	Central socket
42	6.1520.001-A	euro socket
43	3.0628.4022-A	operation panel
44	7.3060.0790	fixing plate for PCB
45	6.4580.001	knob
46		Transparent mask
47	6.3210.101	current transformer
48	6.5030.215	hex spacer
49	3.0628.7015	CNC interface panel
50	3.P628.1057	Control PCB
51	6.2530.100	gas valve
52	3.0628.3002-A	3 phase power PCB
53	6.1220.002	Serial port screen
A1	3.0628.6019-A	FRD PCB
A2	7.7130.001	insulation plate
A3	6.4250.011	IGBT
A4	7.4230.015	FRD sink heat
A5	7.4230.016	FRD sink heat
A6	7.1230.913	plastic holder
A7	6.4010.214	Fast recovery diode
A8	7.4230.017	FRD sink heat

WARNING: There are extremely dangerous voltage and power levels present inside this unit. Do not attempt to diagnose or repair unit by removing external cover unless you are an authorised repair agent for UNIMIG.

1. Over Temp Error Display lamp on.

- Airflow blocked, check for blocked airflow around the unit and correct condition.
- Fan blocked, check and correct condition.
- Unit is overheated, let the unit cool down for at least 5 minutes. Make sure the unit has not been operated beyond Duty Cycle limit.
- Faulty components in the unit, return for repair or have qualified technician repair per Service Manual.

2. Torch fails to ignite the arc when the torch switch is activated

- The system is in SET mode, change to RUN mode.
- Faulty torch parts, inspect torch parts and replace if necessary.
- Gas pressure too high or too low, adjust to the proper pressure.
- Faulty components in the unit, return for repair or have qualified technician repair per Service Manual.

3. No cutting output; Torch activated, power source on; Gas flows; Fan operates

- Torch not correctly connected to the machine, check that torch leads are correctly connected to the machine.
- Work cable not connected to the workpiece, or connection is weak, make sure that work cable has a proper connection to a clean, dry area of the workpiece.
- Faulty components in the unit, return for repair or have qualified technician repair per Service Manual.
- Faulty torch, return for repair or have qualified technician repair.

4. Low cutting output

- Incorrect setting of CURRENT (A) control, check and adjust to the proper setting.
- Faulty components in the unit, return for repair or have qualified technician repair.

5. Difficult Starting

- Worn torch parts (consumables), shut off input power. Remove and inspect torch shield cup, tip and electrode. Replace electrode or tip if worn; replace shield cup if excessive spatter adheres to it.

6. Arc shuts off during operation; arc will not restart when the torch switch is activated.

- Power Supply is overheated, let the unit cool down for at least 5 minutes. Make sure the unit has not been operated beyond Duty Cycle limit. Refer to Section 2 for duty cycle specifications.
- Gas pressure too low, check the source for at least 4bar/60psi; adjust as needed. It is needed to open the machine cover.
- Torch consumables worn, check torch shield cup, tip, starter element, and electrode; replace as needed.
- Faulty components in the unit, return for repair or have qualified technician repair per Service Manual.

7. No gas flow; the power lamp on; Fan operates

- Gas not connected or pressure too low, check gas connections. Adjust gas pressure to the proper setting

8. Torch cuts but low quality

- Current (A) control set too low, increase the current setting.
- The torch is being moved too fast across the workpiece, reduce cutting speed.
- Excessive oil or moisture in torch, hold torch 1/8 inch (3 mm) from a clean surface while purging and observe oil or moisture build-up (do not activate torch). If there are contaminants in the gas, additional filtering may be needed.



HEAD OFFICE:

112 Christina Rd,
Villawood NSW 2163

PH: (02) 9780 4200
FAX: (02) 9780 4210

EMAIL: sales@unimig.com.au

QLD OFFICE:

180 Kerry Rd,
Archerfield QLD 4108

PH: (07) 3333 2855
FAX: (07) 3274 5829

EMAIL: qld@unimig.com.au

VIC OFFICE:

91 Yellowbox Drive,
Craigieburn VIC 3064

PH: (03) 8682 9911
FAX: (03) 9333 7867

EMAIL: vicsales@unimig.com.au

WA OFFICE:

Unit 2/29 Biscayne Way,
Jandakot WA 6164

PH: (08) 6363 5111
FAX: (08) 9417 4781

EMAIL: wasales@unimig.com.au